
SS Steel Wool HFE



**Electric Connections** Glue and Seal end cap 1 (on Left) Modify 3" tube with straight fitting Drill and taps holes at 5/8, +21/2, +21/2 from left of tube on one side drill and tap holes at  $1 \frac{7}{8}$ ,  $+2 \frac{1}{2}$ ,  $+2 \frac{1}{2}$  from left side opposite side, or at 90 degrees from first side. Insert screws with wire connections, and seals and check for shorts.

Modify last endcap with el fitting Glue last cap on with fill fitting at bottom, gas fitting at top. Will always stay full, as long as bubbler under liquid, easy refill, remote mounting if needed